

Installation Instructions

For Wall Sconce 20-4101 & 20-4101E

B164

Page 1 of 2

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Please Note: This fixture is designed to be mounted on a standard wall surface and may not be suitable for all applications. If installing in a non-wood frame application, we recommend consulting a qualified builder or electrician.

To Mount Fixture to Wall (Figure 1)


Component Parts

- A Fixture Assembly
- B Screw Cap
- C Threaded Nipple
- D Lock Nut
- E Crossbar

To Install

Caution: Be sure power is off at the main breaker box prior to installation.

1. Carefully unpack the fixture from the carton.
2. Using two machine screws (not provided) attach crossbar (E) to the electric box.
Note: A new electric box comes with screws. When replacing a fixture, retain the screws for use with the new fixture.
3. Thread the nipple (C) into the crossbar (E) and secure with lock nut (D). Adjust the nipple to proper length to ensure the fixture will fit snugly to the wall.
4. Using suitable wire connectors (not provided), connect the fixture wires to the supply wires, (white to white, black to black, bare copper or green to bare copper or green). If the fixture is wired with twin lead lamp cord, connect the ribbed side to white, and the smooth side to black.
Caution: Make sure wire connectors are twisted on securely and no bare wires are exposed.
5. Carefully tuck all wires behind the fixture, place fixture firmly against the wall and fasten screw cap (B).



(Figure 1)

(continued)

Installation Instructions

For Wall Sconce 20-4101 & 20-4101E

B164


Page 2 of 2

To Install Glass (Figure 2)

Component Parts

- F Socket Tool
- G Retaining Ring
- H Glass
- I Socket

1. Remove retaining ring (G) from socket (I). *Retaining Rings are shipped installed.*
2. Place glass (H) over socket (I).
3. Replace retaining ring (G) and tighten with socket tool (F) to secure glass. *Do not over-tighten.*
4. Install light bulb (*fluorescent bulbs are provided*).
5. Restore electricity at the main breaker.



(Figure 2)

If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!

* Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.